



FIRST
ON THE
WATER

NRS CATARAFT FRAME ALUMINUM FLOOR

SIZES: 66-28"W X 48"L & 72-34"W X 48"L

Components:

- (1) Hinged Aluminum Floor
- (4) Oversized U-bolts
- (8) Washers and locking nuts

Directions:

1. Fold the floor out flat with the diamond plate side facing up.
2. Position floor between lower side rails in desired location.
3. Once everything is lined up, install the U-bolts in the plates at each corner of the floor. Install nuts and washers and tighten securely.
4. Add the oar mounts and tighten all the bolts.
5. Check to be sure that all of the U-bolts are tight. Periodically check the tightness of all nuts and bolts.



2009

S. Main Street
Moscow, ID 83843
800-635-5202
www.nrsweb.com