



FIRST  
ON THE  
WATER

## **NRS UNIVERSAL FRAME**

### **Components:**

- (2) Breakdown Side Rails
- (2) Universal Drop Rails
- (5) Cross Bars
- (1) Seat Bar
- (1) Deluxe Foot Bar
- (1) Pair of Oar mounts
- (4) 9ft Straps
- (8) Strap Slides
- (20) U-bolts
- (40) Washers & Locking Nuts
- (1) Frame Wrench
- (1) Padded Seat



**Note:** Seat is packaged separately.

### **Directions:**

1. Lay out the frame parts as shown in the image above.
2. Attach drop rails to the cross bars as show in picture above and install the U-bolts. Add nuts and washers leaving them loose.
3. Attach the cross bars from step 2 to the upper side rails, offsetting the breakdown joints.
4. Set the additional cross bars and seat bar on the side rails and install the U-Bolts. Add the washers and nuts leaving them loose. Adjust the crossbars so that they fit against the cooler or dry box snugly. If any of the bars need to be re-positioned, it may be necessary to remove the U-bolts to make adjustments.
5. Add the deluxe foot bar and oar mounts. Tighten all the nuts that you previously installed.
6. Check to be sure that all of the U-bolts are tight. Periodically check the tightness of all nuts and bolts.

2009

S. Main Street  
Moscow, ID 83843  
800-635-5202  
www.nrsweb.com