



FIRST
ON THE
WATER™

NRS SKIDGUARD FRAME

Components:

- (2) Side Rails
- (2) Skidguard seats
- (4) Channels
- (8) Seatbolts
- (2) U-bolts
- (4) Washers and Locking Nuts
- (1) Frame Wrench
- (1) Pair of Oar Mounts



Directions:

1. Lay out the frame parts as shown in the image above.
2. Place the skidguard seats textured side up. Add the channels with the flat side against the seat.
3. Place the side rails in the channels with the small holes in the side rails facing up.

Note: There are two different size holes in the rails. This aids in lining up the bolts to the threaded insert in the seat.

4. Add the oar mounts and tighten all of the bolts.
5. When you are storing your frame for long periods of time, it is recommended that you give the raw wood edges a light coat of waterproofing (i.e. Thompson's Waterseal) to keep the wood from weather checking.

2009

S. Main Street
Moscow, ID 83843
800-635-5202
www.nrsweb.com