



FIRST
ON THE
WATER

NRS HYPALON FOOT BRACES

Components:

- (2) Keepers Footpad
- (2) Keepers Rail
- (2) Foot Brace Pocket Patch
- (2) Foot Brace Loop Patch

Materials Needed:

- Clifton Hypalon Adhesive
- 150-180 Grit Sandpaper
- Roller Rasp
- Rubbing Alcohol or Toluene for cleaning
- Pencil
- Lint-Free towel

Directions:

1. With boat inflated, determine the positioning of the patches: Standard positioning aligns the top of the plastic rail with the bottom of the 1-1/2" overlap of material.
2. Clean the gluing area thoroughly with rubbing alcohol or Toluene.
3. Trace the outline of the positioned patches with a pencil.
4. Buff inside the outline with sandpaper, to remove the shine from the material's surface. Patches are pre-buffed.
5. Deflate boat. Follow standard gluing procedures included with the adhesive.

