



FIRST  
ON THE  
WATER

## **NRS MCNETT SEAL CEMENT ADHESIVE**

Contact cement used in the repair of neoprene apparel and sprayskirts

### **Materials Needed:**

Latex Gloves

### **Recommended:**

Use in a well ventilated area (garage or shady area works well).

### **Directions:**

1. Shake tube well before using.
2. Clean and dry repair area.
3. Apply cement to both sides of the repair using the applicator brush.
4. Let the first coat dry for 5 minutes.
5. Apply a second coat to the repair area and allow it to dry for approximately 10 minutes.
6. Press and hold edges of the repair together for 10 seconds.

2009

S. Main Street

Moscow, ID 83843

800-635-5205

[www.nrsweb.com](http://www.nrsweb.com)