



FIRST
ON THE
WATER®

NRS VYNABOND ADHESIVE

Materials Needed:

Latex Gloves
Isopropyl Alcohol

Surface Preparation:

1. Clean surface area with isopropyl alcohol.
2. Cut patch material to size - round the corners.

Directions:

1. Apply small amount of VynaBond evenly onto patch. Press firmly in place. Allow 2 hours minimum dry time before use.

Note: For best results, surface should be clean and dry if possible.

2. For large repairs, apply generous amount of VynaBond onto patch. Press firmly in place squeezing out all air bubbles. Allow 8 hours minimum dry time before use.
3. For underwater repairs, apply generous amount of VynaBond onto patch. Fold patch in half onto itself. Under water, quickly unfold and press firmly in place, squeezing out all air and water bubbles.

Tech Tip: Use rubbing alcohol to clean vinyl. Allow overnight drying whenever possible

2009

S. Main Street

Moscow, ID 83843

800-635-5205

www.nrsweb.com