



FIRST
ON THE
WATER

NRS AQUASEAL ADHESIVE & COTOL ACCELERATOR

Use this product for neoprene repairs and latex gasket replacement. Cotol is a cure accelerator and pre-cleaner to be used with Aquaseal.

Materials Needed:

- Aquaseal
- Cotol (speeds the tack time to 15 minutes)
- Mixing cup
- Applicator (flat popsicle stick works well)

WARNING- Fully cured Aquaseal is slippery when wet!

Cotol/Aquaseal Mix:

- Mix 1 part Cotol to 3-4 parts Aquaseal.
- Mix thoroughly until compound appears white.

Repair with patch:

- Clean damaged area with Cotol.
- Trim loose treads.
- Cut a Patch so that it has rounded corners and is at least 1/2" bigger than the tear
- Create backing with wax paper. This will keep the glue from leaking through and sticking to other places on the garment.
- Apply Aquaseal to garment side only.
- Apply Patch.
- Place another piece of wax paper over the patched area, then place a heavy flat object (i.e. heavy book) over the top of the wax paper and leave overnight.
- Keep repaired surface level overnight and avoid contact with other surfaces.

High wear areas: On high wear areas, apply thin coat of Aquaseal for flexible abrasion resistance.

Repair holes and tears:

- Clean damaged area with Cotol.
- Create backing with wax paper. This will keep the glue from leaking through and sticking to other places on the garment.
- Fill void and 1/4" beyond edge with Aquaseal mix.

Gasket Replacement: Gasket Repair Instructions are online at www.nrsweb.com or call for assistance.

2009

S. Main Street
Moscow, ID 83843

800-635-5205

www.nrsweb.com