



FIRST  
ON THE  
WATER™

## NRS BASIC FISHING FRAME

### Components:

- (2) Side Rails
- (1) Cross Bar
- (1) Foot Bar
- (1) Seat Bar
- (1) Action Seat Bar
- (10) U-Bolts
- (20) Washers and Locking Nuts
- (1) Frame wrench
- (1) Pair of Oar Mounts
- (1) Padded Raft Seat
- (1) Action Swivel Seat



Note: Seats are packaged separately

### Directions:

1. Lay out the frame parts as shown in the image above.
2. Set all bars on the side rails and install the U-Bolts. Add the washers and nuts leaving them loose. Be sure that the side marked "Front" on the seat plate faces forward. If any of the bars need to be re-positioned, it may be necessary to remove the U-bolts to make adjustments.

Note: Bolt pattern on Action Seat plate designed for Action Swivel Seat only.

3. Add oar mounts and seats.
4. Check to be sure that all of the U-bolts are tight. Periodically check the tightness of all nuts and bolts.

2009

S. Main Street  
Moscow, ID 83843  
800-635-5202  
www.nrsweb.com